



**Staging Diagram**

1	E	G	2	G	B
7	F	G	8	G	E
3	C	9	G	A	
4	E	G	10	G	B
5	G	B	11	D	
6	C	12	C		

- Key**
- Primary signal head and pole
  - Secondary signal head and pole
  - Signal head including directional arrow
  - Pedestrian and cycle push button and 'Wait' display
  - Pedestrian push button
  - Vehicle approach loop
  - Footway

# BEXHILL TO HASTINGS LINK ROAD

The map is reproduced from Ordnance Survey material with the permission of Ordnance Survey on behalf of the Controller of Her Majesty's Stationery Office. Crown copyright. Unauthorised reproduction is prohibited. All rights reserved. Licence number: 100019501, (6837).

**Figure : 3A.23**  
**QUEENSWAY JUNCTION**

<b>Scale</b>	<b>1:1000</b>
<b>Sheet</b>	<b>1 of 1</b>
<b>Revision</b>	<b>02</b>
<b>Revision</b>	<b>April 2007</b>

**Transport & Environment**